


Aiologs Sequential Shifter

User Manual

The driver is install automatically
Reconnect device after installation

Software for control lightning
<https://shop.aiologs.net/files/led.zip>


Customers service
aiologs.net@gmail.com



Mounting options

Mounting plate

Mounting available
on left & right side



Mounting options

Clamp

